

Please read the manual carefully before using this product.


Thank you for your purchase and use of XGIMI products, for your safety and interests, please read the manual carefully before using this product. If you are not in accordance with the product manual operation or attention, resulting in any personal injury, property or other losses, XGIMI will not be liable.

About the manual (hereinafter referred to as "manual")

The copyright belongs to XGIMI; The trademarks and trade names mentioned in the manual belong to their respective owners; if the manual is inconsistent with the actual product, the actual product shall prevail in kind.

If you have any objection to the contents or terms of the manual, please submit a written objection within seven days after the purchase, otherwise you have agreed to understand and accept all the contents of the manual.

XGIMI reserves the right to interpret and modify the manual.



Earphone jack S/PDIF USB 2.0 USB 3.0

HD Port1/ARC HD Port2 WLAN Power

*使用S/PDIF接口时请使用标准S/PDIF线缆
*Please use HD Port2.0 cables for HD Port2.0 interfaces



*Move the function switch to the left (VOL): Volume "+" & "-" keys to adjust volume;
Move the function switch to the right (Focus): Focus "+" & "-" keys to adjust focus.

2 Power off

- In projection mode, click the "Power" on the machine to turn off the device


* Note: Please put two AAA batteries into the remote control.

1 设备开/关机

- 接通电源，等待指示灯熄灭，单击顶部电源键，设备开机
- 在设备开机状态下，单击顶部电源键，设备关机

3 自动调焦/遥控器调焦

- 当自动调焦功能开启时，设备开机后画面将自动调节清晰
- 将遥控器底部功能开关拨动至右侧(Focus)可触发自动对焦



- Focus "+"& "-" keys to adjust focus

4 Remote control functions

- Focusing functions
The focusing function is enabled after moving the function switch, at the bottom of the remote control, to the right (Focus); Pressing "volume +/-" to adjust the volume when function key is at the left.
- Menu/shortcut key functions
Shortly press the "Menu" to enable the menu key functions; long press the "Menu" to enable the shortcut key functions

5 音响模式




Chengdu XGIMI Technology Co., Ltd.

Building A4, Tianfu Software Park, High-tech zone, Chengdu, China
+86-28-67599891 www.xgimi.com service@xgimi.com

进入音响模式


按机身 "Audio" 键，进入音响模式。在投影模式下，按下遥控器 "Audio" 键，在菜单中选择音响模式进入。



退出音响模式



- 单击设备顶部 "Audio" 键关机




- 按下遥控器 "Audio" 键进入投影模式

音响模式使用

- 进入音响模式后，按下机身 "Audio" 键开始播放音乐

- 在音响模式下，可通过手机蓝牙搜索到设备；当手机连接后，可通过蓝牙播放手机上的歌曲

- 当需要通过蓝牙连接其它手机进行歌曲播放，可通过按下机身 "Audio" 键或遥控器菜单键，重新进入可被连接状态



播放控制

在本地歌曲播放过程中，按下机身 "Audio" 键或遥控器 "Audio" 播放/暂停；按下机身 "Audio" 或者遥控器 "<" ">" 键进行切歌。

6 XGIMI Assistance

Download "XGIMI Assistant" application from App store on your devices.

- Mobile phone remote: device can be easily controlled by mobile phone.
- Mobile phone resource: send the resource from mobile phone to device to view photos or videos.



7 More Functions

System Upgrade

- Online Upgrade
Online upgrade through system settings
- Local Upgrade
1、Copy the firmware to the packing list of U disk in FAT32 format
2、Insert the U disk into the USB2.0 interface and select the U disk upgrade.

强制升级
关机插电状态下，将升级固件拷贝到格式为 FAT32的U盘根目录下；将U盘插入USB2.0接口接通电源，然后长按 "Audio" 键，等待机器指示灯快速闪烁，进入强刷模式，松开按键

System Function

- The manual provides instruction of basic functions. For detailed operation and other functions, please check the electronic instructions on the main page: <https://forum.xgimi.com/download-firmware.html>.

* Note: Due to the continuous updating of the system function, please refer to the actual functions.

Usage Notice

How to use the equipment correctly:

- Do not turn the lens towards the human eyes to avoid the strong light from the lens damage the eyes.
- Do not block the air inlet and outlet of the device to avoid damage to the internal electronic devices.
- Do not use paper, cloth, and other cleaning tools to wipe the lens directly to avoid damage to the lens; use clean air blowing to remove dust on the lens' surface.
- Do not use chemicals, cleaning agents or clean water to clean the device, as well as to avoid rain, moisture and mineral liquid corrosion circuiting board.
- Please put the device and its parts and accessories in the place where children cannot touch.
- Please ensure that the device is being used in a dry and ventilated environment.
- Do not store the device in hot or cold environment, high (low) temperature will shorten the life span of electronic devices. Enabling operating environment could be 0-40℃.
- Do not put the device in any heating equipment (such as drying machine, microwave oven, and etc.)
- Do not squeeze the device or place heavy objects on the device to avoid damage to the device.
- Do not throw, knock, or violent shaking the device, resulting in damage to the internal circuit board.
- Do not attempt to disassemble device. If you have any questions, please contact the after-sales service of XGIMI.
- Do not maintain any products. If the device or any parts cannot work normally should promptly consult the after-sales service or factory repair.
- If the device has not been using for a long time, please cut off the power supply.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The user manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the information required by this section may be included in the manual in that alternative form, provided the user can reasonably be expected to have the capability to access information in that form.
For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual:
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

CE RoHS

FCC ID:2AFENXHAD01

XGIMI
极米 无屏电视

H2